



**NEUTRAL SAFETY & BACK-UP SWITCH
RE-LOCATION CONVERSION
3-SPEED AND 4-SPEED AUTOMATICS**

1968-81 Pontiac and 1973-81 Chevy

TH350 & TH400

 **SW652**



TH200-4R, TH700-R4 & 4L60

 **SW653**



TH350 & TH400

- 1 Remove the console and the shifter from the car.
- 2 Purchase a **Standard Motor Products NS7** (or equivalent) Neutral Safety Switch. Available Amazon or Ebay. You will need to remove a small metal tab on the metal back plate.
- 3 The Forward blades are Park-Neutral, and the Center blades are Reverse.
- 4 In order to secure the mount for the NSS you must drill 2 holes and use either pop rivets or bolts (not provided). **Install the PIN before drilling to locate the holes.**
- 5 Follow the Instructions.



TH200-4R, TH700-R4 & 4L60

- 6 Remove the console and the shifter from the car.
- 7 Use the SHIFTWORKS® Neutral Safety Switch provided.
- 8 The purple wires are Park-Neutral, and the green and pink wires are Reverse.
- 9 In order to secure the mount for the NSS you must drill 2 holes and use either pop rivets or bolts (not provided). **Install the PIN before drilling to locate the holes.**
- 10 Follow the Instructions.
- 11 The purple wires are Neutral Safety, pink & green Backup.

