



1973-77 CUTLASS/OLDS SHIFTER CONVERSION KIT

SC2352 for 4-Speed Autos

SC2352-05 for 4L80E, 4L85E



KITS TO CONVERT THE FACTORY CONSOLE SHIFTER TO CABLE OPERATION WITH ALL DETENTS AVAILABLE.

WWW.SHIFTWORKS.COM

© 2014-2021 SHIFTWORKS®

SHIFTER CONVERSION

1. Remove the console. Take care with the wire harness.
2. Disconnect the old cable and remove the shifter from the car.
3. Unbolt and replace the factory detent with the SHIFTWORKS® detent supplied in your kit.

CABLE INSTALLATION

4. Install the control cable bracket and lever on the Transmission and install the control cable.
5. With the transmission and shifter lever both in PARK and the emergency brake on, adjust the distance from the cable pin to the cable mount bracket at the transmission to 6.75 inches.
6. Tighten the pin nut. You should now be almost in adjustment. Check the shifter travel, and readjust as necessary.



WWW.SHIFTWORKS.COM

© 2014-2021 SHIFTWORKS®



1973-77 CUTLASS/OLDS SHIFTER CONVERSION KIT

SC2352 for 4-Speed Autos

SC2352-05 for 4L80E, 4L85E



KITS TO CONVERT THE FACTORY CONSOLE SHIFTER TO CABLE OPERATION WITH ALL DETENTS AVAILABLE.

WWW.SHIFTWORKS.COM

© 2014-2021 SHIFTWORKS®

SHIFTER CONVERSION

1. Remove the console. Take care with the wire harness.
2. Disconnect the old cable and remove the shifter from the car.
3. Unbolt and replace the factory detent with the SHIFTWORKS® detent supplied in your kit.

CABLE INSTALLATION

4. Install the control cable bracket and lever on the Transmission and install the control cable.
5. With the transmission and shifter lever both in PARK and the emergency brake on, adjust the distance from the cable pin to the cable mount bracket at the transmission to 6.75 inches.
6. Tighten the pin nut. You should now be almost in adjustment. Check the shifter travel, and readjust as necessary.



WWW.SHIFTWORKS.COM

© 2014-2021 SHIFTWORKS®