

ASSEMBLY INSTRUCTIONS

LINEN CLOSET CABINET

VLC1884

Checking Your Parts.

The following parts are included in the carton. Separate and check to see if all parts are accounted for before starting assembly. If you are missing parts contact the store where you bought the product or call JS INTERNATIONAL INC and request that the part(s) be sent to you.

A - Door Face frame (1)	B - Side Panels (2)	C - Top, Middle (2), & Bottom Panels (4)
D - Back Panel (1)	E - Shelves (4)	F - Toe Kick (1)
G - Shelf Holders (16) & Handle Hdw		

Assembly Steps

STEP 1: Remove the linen closet unit parts and make sure all is accounted for. Place the Door Face frame (A) down on a flat soft surface to avoid scratching the cabinet.

STEP 2: Insert two Side Panels (B) into the grooves on Face frame (A). Align the plastic half sections of the camlock connectors. Confirm all is flush and lock connectors with a screwdriver by turning the screw located on the camlock connector to the right 1 80 degrees, reference figure A.

STEP 3: Slide the Top, both Middle and Bottom Panels (C) into the grooves of Side Panels (B) and Face frame (A). These are slightly larger, than the shelves in size.

STEP 4: Position Toe Kick (F) onto Side Panels (B) at the cut out at the base of the cabinet. Align and confirm that all is flush and lock connectors as in step 2 above.

STEP 5: Place Back Panel (D) into the grooves of Side Panels (B) making sure that the finished side of panel is to the inside of the cabinet. Once the Back Panel is aligned and fully seated fasten the two camlock connectors at the bottom of the cabinet. Now gently raise the cabinet from the top and stand upright. Open the cabinet doors, reconfirm that all is aligned and flush, and lock connectors at rear inside of cabinet.

STEP 6: Your cabinet is now ready to be placed in position. PLEASE NOTE: IT IS RECOMMENDED THAT THE CABINET BE FASTENED TO THE WALL FOR STABILITY. Use a 1 1/2 or 2 inch drywall screw not provided and mount through the thickest part of the back panel into a wall stud in at least two places. After securing the cabinet to the wall insert the Shelf Holders (G) into the holes in the cabinet at the desired height and slide in Shelves (E). Two types of Door Hardware are provided for this cabinet. Please install as follows:

- a) BRASS KNOBS - can be mounted thru predrilled holes in doors.
- b) HANDLES - can be mounted after drilling through second pilot hole in each door.