



CAMP LINE KIT

For videos, FAQ's, and more please visit GearAid.com/blogs/help

1 TO ATTACH CAMP CARABINER TO 550 PARACORD:

1. Hold Camp Carabiner up to paracord and press slot into cordage.
2. Twist clockwise to lock cord into attachment slots until anchored

Note: Bail (sliver clip) must be closed to hold heavy items – max weight load: 25 lbs.

2 TO SUSPEND A LINE

1. Take cord end, pass through top of Line Tensioner #1 hole, and tie figure 8 knot.
2. Wrap cord end and Line Tensioner counter clockwise around tree/roof rack (Fig. A), passing cord loop up through slot #2 and down through slot #3 (Fig. B).
3. Slide Line Tensioner along cord until taut.
4. Repeat steps for other end of cord to complete line set up.

Tip: For a shorter line, wrap the cord around the tree multiple times.

