



TO SUSPEND A LINE

1. Take cord end, pass through top of Line Tensioner #1 hole, and tie figure 8 knot.
2. Wrap cord end and Line Tensioner counter clockwise around tree/roof rack (Fig. A), passing cord loop up through slot #2 and down through slot #3 (Fig. B).
3. Slide Line Tensioner along cord until taut.
4. Repeat steps for other end of cord to complete line set up.

Tip: For a shorter line, wrap the cord around the tree multiple times.

