

TRIUMPH DAYTONA 675/R & MOTO2 765 DIY WINDSCREEN INSTALL

PLEASE READ BEFORE MOUNTING YOUR WINDSCREEN

Installation Manual for Triumph Daytona 2013 to Present Windscreen Install

Thank you for purchasing one of Zero Gravity's windscreens which has been designed and manufactured to give years of safe and fun riding. This instruction manual gives you an in-depth look at the installation process. To receive further assistance or parts please call Zero Gravity[®] Sales Department at 805-388-8803 or e-mail at **techinfo@zerogravity-racing.com**.

Helpful hints: Use metric tools, clean hands, and put the bike on a center stand. Do not pry on the screen excessively, as it will break without much warning.

Mounting Your Zero Gravity Windscreen

Remove both of the mirror fasteners located underneath the mirror foot. Remove both of the mirrors. Remove factory windscreen by unscrewing the four top allen screws. Remove four wellnuts, pulling them down from the bottom. When removing the windscreen, pull towards the back since it's sandwiched in between two layers. **BEFORE** installing ZG's windscreen on to the bike, apply vibration damping tape that is supplied in the ZG bag. To apply, adhere tape in front of the step at the top of the marker light as shown. To install the ZG windscreen, reverse the uninstall instruction sequence.

Note: For best results, clean surface of the substrate with alcohol, removing any surface contaminant's such as dirt, dust, processing oils or waxes. Apply tape once the surface is completely dry.



Locate the upper marker light

Pad Specs: 1/2″ Square pad x 1/8″ Thick



WWW.ZEROGRAVITY-RACING.COM