

Ford Focus ST MK3.5

Stainless Steel Sports Grille Mesh Upper

Kit Contents: -

1. off Upper Mesh Grille
3. off No6 x 1 ½" Screws
2. off No6 x ¾" Screws

Tools Required

P2 Screwdriver



Grille Fitting Instructions

1. Removing existing moulding as shown in fig 1.
2. Fit masking tape around aperture to protect paint (fig 2).
3. Trim all the plastic lugs off as shown in fig 3, 4 & 5. (We advise for appearance purposes once you have trimmed the lugs off, touch the end of the lug paintwork up to match your car colour).
4. Locate the new upper grille into position, check that it is central then locate the top 6 brackets (Fig 6)
5. Now that the grille is in position check that all the brackets have engaged properly, you can do this by using a thin screwdriver through the mesh as shown in (fig 7).
6. Fasten the lower part of the grille to the existing aperture using screws provided making sure the grille is tightly fixed into position (fig 8) (Do not over tighten screws).
7. The grille is now complete.



Fig 1



Fig 2

