

Ford Focus ST MK3

Stainless Steel Sports Rear Grille Set Kit

Kit Contents: -

- 2. off Rear Grille
- 6.off No.6 x 1½" Screws



Rear Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate the grille into the aperture.
3. Whilst holding the grille centrally in the aperture, screw the 3 pins through the locating diamonds into the existing aperture (fig1 & 2).
4. Repeat for opposite side grille.
5. Remove the tape and the grilles are now complete.



Fig 1



Fig 2