

Ford Puma ST Stainless Steel Sports Grille Mesh Upper

Kit Contents: -

1. off Upper Mesh Grille
7. off 1" Screws



YouTube Tutorial –

<https://www.youtube.com/watch?v=wxyX61bE1Jk>



Upper Grille Fitting Instructions (It is advised to get someone to hold the grille in place whilst you fit to the car)

1. Locate the grille into position, check that it is centralised in the aperture (fig 1).
2. Now that the grille is in position fasten the grille to the existing aperture using screws provided Starting with the centre screws 1st (fig 2) then the outer screws making sure the grille is tightly fixed into position (fig 3&4) (Do not over tighten screws).
3. The grille is now complete.

