

# Ford Transit Custom Stainless Steel Sports Lower Grille

**Part No. ZFR50313 WITH TOWING EYE**

**Part No. ZFR49813 WITHOUT TOWING EYE**

## **Kit Contents:**

- 1 off Lower Grille
- 4 off No 6 x 1 ½” Screws



**If you own a Ford Transit Custom with the additional skirt on the lower bumper. Please complete page 2 of the fitting instructions before continuing. Also please note that if you have a plastic trim on the lower grille moulding this will also have to be removed as this will affect the fit and cause the sensors to keep going off.**

## **Lower Mesh Grille Fitting Instructions**

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate grille to the aperture and guide upper centre brackets through the aperture.
3. Carefully push and guide the lower centre brackets behind the aperture and check they have engaged properly by using a thin screw driver as shown in fig 1.
4. Once the grille is securely in position fix the grill to the plastic using the 4 screws as shown in fig 2.
5. The Grilles are now complete.



**THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.**

### Lower Skirt Removal

1. Unscrew the skirt from the bumper (2 screws each side, fig1).
2. Remove the skirt from the van. (fig2).
3. Fit the grille as page 1 of this fitting instruction.
4. Re-fit the skirt and your grilles are complete (fig3 and 4).



Fig 1



Fig 2



Fig 3



Fig 4