

VW T4 Van Long Nose Stainless Steel Sports Upper Grille Kit

Kit Contents: -

- 1. off LH Side Grille
- 1. off RH Side Grille
- 4. off Screws No 8 x 1/2"



Mesh Grille Fitting Instructions

1. Open the Bonnet
2. Offer the Mesh Grilles over the existing plastic grille, allowing the bottom Brackets to pass inside the aperture and clip into position Fig 1.
3. Push the grilles back into position so that the grilles fit evenly in the aperture
4. Screw into position using the screws provided through the brackets on the grille Fig 2. (Do not over tighten as this will strip the plastic thread formed by the self tapping screw)
5. The grilles are now complete.

