

## Vivaro Van MY 2007-2010 Stainless Steel Centre Sports Grille

### Kit Contents: -

1 off Centre Grille

### Tools Required: -

Masking tape  
Thin flat screwdriver



### Mesh Grille Fitting Instructions

1. It is advised that masking tape is used to protect the original surfaces prior to assembly, position the tape to allow for easy removal after the grille has been fitted.
2. Offer the grille to the aperture, locating the top 2 wire brackets first, push up against the original plastic and secure the 2 bottom clips behind the original trim, Fig 1.
3. Ensure that the clips have engaged, if required use a long screwdriver to secure whilst putting a little pressure on the front face of the grille, Fig 2.
4. Remove the masking tape and assembly is complete.



Fig 1



Fig 2