



Mobile: +1 303 598 5776 • E-mail: [jtmcmaster2016@gmail.com](mailto:jtmcmaster2016@gmail.com)  
• <https://j-t-mcmaster.myshopify.com> •

***Instructions on applying your ceramic transfer:***

Congratulations on purchasing your transfers from J.T.McMaster, the transfer specialists!

- 1.) Remove the interleave paper only when you are ready to start applying your transfers.
- 2.) Decide more or less where you want to place them on your substrate.
- 3.) Soak in cold tap water. Change the water regularly so as to keep it clean and free of residual glue from the backing paper.
- 4.) Do not leave the transfer in the water, simply soak and remove from the water. Wait a few seconds and you will find you are able to gently move the transfer around on the gum-coated backing paper.
- 5.) Slide the transfer from the backing paper onto the substrate and discard the backing paper.
- 6.) Position your transfer correctly and sponge or squeegee down until the transfer is free of visible water bubbles. Once you are satisfied, leave your transfer to dry in position on your substrate. It is recommended that the transfer be left to dry overnight.

Test fire a sample or two to get correct firing temperature (we recommend 780° Celsius or cone 017) before firing an entire kiln load. Reds can be temperamental... do not place them too near the elements in the kiln as this can cause the colour to fade.

Have fun and please don't hesitate to contact us with any questions or comments.

Sincerely

The J.T.McMaster Team