

## CARROBOT C2 LITE FIRMWARE UPDATE FOR ANDROID 8 USERS FOR SCREEN CASTING

*This update will allow Android 8 OS users to screen cast by wire only.*

### **How to upgrade the Carrobot Lite hardware for Android 8 OS:**

1. Install Carrobot C2 Lite APK file onto your android 8 OS Device;
2. Find the "settings" on the Carrobot C2 Lite APP;
3. Upgrade the hardware in the settings (please keep the HUD power on all the time while it is upgrading)

Note: Once it is updated, there are now two android models:

**Android Model 1:** supports all android versions, but this is designed especially for Android 8 or above users - supports wired way for screen cast only.

**Android Model 2:** for Android 7 versions or below - supports both wired and wireless for screen cast.

There are now 3 mode users can choose from the power button on the HUD:

Android Model 1, Android Model 2 or iOS.

### **Special instructions on some Samsung phones:**

The user can adjust the phone resolution (usually from the highest level down to medium) to make a full phone screen cast if there are only some part of phone screen that can be viewed onto the HUD.

**Note:** For Android 7 or below phone users if you use the new app and upgrade the Carrobot C2 Lite's hardware.

Your phone may disconnect from the HUD when you open the Carrobot APP if you cast your phone screen to the HUD by wireless way first.

### **Solutions:**

Option 1: Reconnect the HUD with the phone one time and everything will be ok.

Option 2: Open Carrobot APP first then cast the phone screen to the HUD by wireless way.