
blossom & brush

FITTING GUIDE

01 Fill a clean spray bottle with water and a squeeze of washing up liquid.

02 Use this solution to thoroughly clean the inside of your windows.



03 Lay your window film out onto a clean, flat, surface. For frosted film, lay with the paper side facing up. For clear film, lay with the printed side facing up.

04 Peel back the protective paper or film.



05 Slowly peel back the paper or film, leaving the windowfilm flat on the table.

TAKE CARE TO MAKE SURE THE WINDOW FILM STAYS FLAT ON THE TABLE SO THAT IT DOES NOT LIFT AND STICK TO ITSELF.



-
- 06 Spray the window with a fine mist of the solution until it is wet all over.

IT IS VERY IMPORTANT THAT THE GLASS IS VERY WET TO AVOID THE FILM STICKING BEFORE YOU HAVE POSITIONED IT.



-
- 07 Carefully lift your film and apply the sticky side to the wet glass. If you have a large window, get someone to help by taking two corners each to avoid the film sticking to itself.



-
- 08 Slide your film into position on the wet glass.

-
- 09 Use the black felt side of your squeegee to push all of the solution to the edges, and wipe away with a clean, lint-free cloth.



-
- 10 Repeat step 9 with the hard side of the squeegee.

-
- 11 Wipe away excess water.



LEAVE THE WINDOW FILM FOR 24 HOURS TO DRY COMPLETELY.