

Pin Installation Guide

Your Catalyst Pedals are supplied with two sets of pins – a bag of 5.5mm & 8mm. This is so you can customize the pedal to suit the type of riding you are planning to do.

We strongly recommend that you use a threadlock compound on your pins, which can be purchased from your local hardware or machine shop.

You can fit the pins in a few minutes. If you haven't done it before, we suggest you follow this simple procedure.



Decide which pins you would like to fit to your Catalyst pedals.

Your pedals will come supplied with a 2mm hex wrench / Allen key tool, which will be in the bag with the 8mm pins.



Dispense a small amount of the threadlock solution onto the bottom third of the pin. Allow 30-40 seconds for the threadlock to start to dry. Line up the pin with the first hole, ensuring that it is not on an angle. Gently turn the pin clockwise until you feel the thread engage.



Once the thread has engaged & turns easily, use the tool provided to gently screw the pin clockwise into the pedal. As soon as the pin becomes stiff to turn or stops, then stop. Do not overtighten the pin.



PEDALING
INNOVATIONS



The threadlock will ensure it remains fast.

Repeat the process with each pin until all the holes are filled. You will have a few pins left over as spares.



Once the threadlock has had the recommended setting time the pedals are ready for use.

To remove the pins insert the tool into the pin head & carefully turn in an anti-clockwise direction.

If you have any questions or queries regarding your pedals, please feel free to get in touch with us via the contact form on our web site.

Ride Strong.