

Sana WALL SCONCE

INSTALLATION GUIDE






DANGER: ELECTRIC SHOCK RISK. FOR YOUR SAFETY, TURN OFF ELECTRICAL POWER BEFORE BEGINNING INSTALLATION AND USE CAUTION WHEN INSTALLING.

+1 888.399.9905 www.vault-light.com | sales@vault-light.com





1




2



+-

REF/SKU : BRWL7025

Lampholder: E27*2 MAX 40W



000	99 90 90 90 90 90 90 90 90	0		000	
rion pipe L40	100	000	on pipe L5.	rion pipe	L400

Α	320	120	4
В	350	135	6
С	380	150	6
D	410	170	6
Е	445	185	6
F	475	195	6
G	505	210	6
Н	540	225	6
	570	240	6
J	600	255	5

L(mm) M(mm) PCS

Installation program

- Install the hanging board on the wall. Use screws to lock.
 The wall box is aligned with the hanging plate hole.
 Lock with screws.
- Connect the wires in the junction box to the external power cord.
- 3. Prepare the E27 light source, install it on the corresponding lamp cap, and tighten it.
- 4.Prepare the glass rod and hang it on the corresponding hole.

ATTENTIONS



- 1.Do not disassembly this products
- 2.Do not strike or shake strongly
- 3.Do not wipe with ethyl alcohol, gasoline or paint thinners etc.

Assembling Attentions:

- 1.Components should be on desk, without any defect or out of shape.
- 2.The bearing of mounting plate should be enough for the lamp, expansion screw is needed for big chandeliers.
- 3..Once wight of chandelier is over 3kg, it should be fix with Embedded chain hoist to make sure not pressure to wire 4.Incandescent light bulb can not be installed to combustible hook directly, can not cling to fabric shade, power can not higher than maximum marked on lamp.