






020 33 Vanity
 Bathroom Cabinet
 INSTALLATION GUIDE

DOWELL

Hardware			Tools	
No.	Draw	Qty		
A		2pcs		
B		2pcs		
C		4pcs		

IMPORTANT
 Vanity must be installed 16" away from the heat above 122 °F (50 °C).

Note: Skip steps 2 to 7 if you don't need to install the vanity on the wall.

