

# POLARIS 1

## RETROFIT RAIN SHOWER SET INSTALLATION GUIDE

Please read the guide prior to installation. If you have any questions, don't hesitate to contact us.

**Please watch the installation video from  
[Granastore.com/instructions](https://granastore.com/instructions)**

GranaStore Inc  
[granastore.com](https://granastore.com)  
[help@granastore.com](mailto:help@granastore.com)  
t. 727 686 4292

The piping must be properly flushed prior to installation. Turn off water supply.

1. Add thread seal tape (plumber's tape) to the threads of the connector.
2. Make sure the shower pipe fitting is clean of dirt. Screw the connector into the shower outlet. Control the alignment (threads down).
3. Attach the shower column to the connector.
4. Attach the diverter to the shower column.
5. Attach the double-sided tape (A) to the mounting plate (B). Place the wall mount to the peg behind the diverter (C).
6. Set the shower column straight using a level. Mark the placement for the wall mount to the wall. (Go to step 7 if using screws.) Clean the wall area behind the diverter to secure a solid connection. Remove the liner from the double-sided adhesive (5.A). Firmly press the mount to the marked spot on the wall for 30 seconds.
7. Mounting with screws (optional): Mark the location of the screws. Drill holes. Add screw anchors and silicone to the holes. Attach the wall mount.
8. Screw in the flange.
9. Adjust the wall mount to ensure the shower column stands parallel to the wall and tighten the 2 set screws.
10. Attach the upper pipe into the connector.
11. Fasten the set screw under the pipe.
12. Ensure the gasket (D) is correctly in place and attach the shower plate. Wash your hands or use gloves to avoid getting grease on the head and nozzles.
13. Attach the handheld shower. Notice the orientation of the hose (hex end to diverter, conic end to handheld)

Open water supply and ensure there are no leakages.



