

3D KNOCKDOWN DECOY CONVERSION INSTRUCTIONS

- Step 1 Disassemble the knockdown decoy by sliding the retaining sleeve down the stake until it comes off.
- Step 2 Remove windsock from the stake.
- Step 3 Slide stake thru the hole on top of the head (pic 1).
- Step 4 Insert spacer provided in the conversion kit and slide up the stake until it firmly rests against the head (pic 2).
- Step 5 Insert stake thru top grommet on windsock then the back support and support sleeve and finally thru the bottom grommet. Slide the parts upward until they reach the desired position (pic 3).



(pic 1)



(pic 2)



(pic 3)



Completed Conversion