

AllSpice Wall Mounting Notes

Disclaimer: *These are rough guidelines and we give no guarantees to the safety and security of wall-mounting since the rack was designed to rest on a countertop. We very much recommend hiring a professional to be certain you have mounted it safely!*

You will need:

- Stud finder
- (4) ¼ x 3" Lag bolts (or larger)
- (4) ½ - ¾" Washers
- 5mm Spacer for back (can also use washers)
- Drill/socket extender for power driver

Find Studs: The rack is 35+ lbs. without any spices, so it is important to go into the studs (not just drywall!) and hopefully you can span two studs.

Hardware: Use four lag bolts with relatively large washers to spread the weight out on the mdf backer board. I recommend at least ¼" x 3" lag bolts into the wood of the studs with ½ - ¾" washers.

Bolt Positioning: Pre-drill holes through the back of the rack and into the studs with an extended bit (the size of the shaft of the lag bot minus the threads). Note where the jars rest on the inside of the rack and avoid those areas as the heads of the lag bolts will protrude a bit.

Spacer: It is essential to add a 5mm slat of wood or use washers as spacers on the back to bridge the distance between the back edge of the rack and the wall. If you skip this step, the back panel will crack when you tighten the lags against the wall!

Installation: Tighten lag bolts (with washers inside the rack) using the extended socket driver, to pull the rack snugly against the wall. Test with some weight to be sure the rack is secure.