

Swiss Madison  
well made forever

SM-1T257

SUBLIME II

Floor anchor  
placement  
template

Wall

Place template on the  
floor above the flange.

Outer Rim of Flange

X

4 1/2"

Drill here

X

Anchors

4"

7 3/8"

Drill here

X

Anchors

Front of Toilet

