



Bumper Guard for R&B Wire® Poly Bumper Trucks



cart sold separately

Benefits & Features

- Custom, made-to-order bumper guards
- Made of premium quality materials
- Protects hallway walls, doorways and elevators
- Easy installation and stays securely attached

Specifications

Made for R&B Wire® Poly Bumper Trucks

PRBW-S fits Cart Circumference **LESS** than or **EQUAL** to **138"**

PRBW-M fits Cart Circumference **GREATER** than **138"** & **LESS** than **150"**

PRBW-L fits Cart Circumference **EQUAL** to or **GREATER** than **150"**

Measuring Instructions for Custom-made Bumper Guards

Determine the **CIRCUMFERENCE** by measuring around the widest point of cart's rubber edge.



Item # PRBW

Bumper Guard for R&B Wire® Poly Bumper Trucks

IMPORTANT: Exact measurements are required.



Widest point of cart's rubber edge

VERY IMPORTANT:

DO NOT calculate circumference by adding together the cart's length and width dimensions, as this method only works for an exact rectangle (and not for carts with rounded corners).

IMPORTANT:

- Physically measure each cart.
- **EXACT** measurements are required.
- **Custom-made items are non-returnable.**
- The following measurements are required for EACH CART SIZE:

- **CIRCUMFERENCE**
- **LENGTH** and **WIDTH**

HELPFUL TIP:

- Wrap string around the widest point of cart's upper edge. (Use tape to secure the string in place.)
- Cut or mark string.
- Measure string's length with measuring tape.