



## Installation Instructions

1. If possible, remove vacuum manufacturer's vinyl bumper.
2. Thoroughly clean the vacuum-head with a non-bleach and non-oil-based cleaning solution.

**Note:** Dirt will prevent Velcro® adhesive from adhering well.

3. Peel plastic backing from Velcro and attach strips directly to the hard plastic frame of the vacuum-head as shown in Figure 2.

**Note:** Do not attach Velcro to vacuum manufacturer's vinyl bumper.

4. For best results, install bumper 24-hours after attaching Velcro.

**Note:** Adhesive reaches maximum strength 24-hours after Velcro installation.

5. Center, stretch and attach the bumper as shown in Figures 3 and 4.
  - a. Bumper must completely cover the Velcro to prevent dirt from attaching to adhesive.
  - b. Bumper must not hang below the vacuum-head, as this will impede the vacuum's performance.
  - c. Do not cover vacuum's ventilation system.

## Care Instructions

Remove dust and debris with a vacuum attachment or lint-roller.  
Machine washable; air dry.

Figure 1



Figure 2



Figure 3



Figure 4

