

Installation Instructions

1. **If possible**, remove vacuum manufacturer's vinyl bumper.
2. **Thoroughly clean vacuum-head with a non-oil-based cleaning solution. Clean again with the provided alcohol wipes.**
Note: Dirt will prevent Velcro® adhesive from adhering well.
3. Peel plastic backing from Velcro® and attach strips directly to the hard plastic frame of the vacuum-head as shown in Figure 1.
Note: Adhesives adhere better to plastic than vinyl.
4. For best results, install VacuBumper™ 24-hours after attaching Velcro®.
Note: Adhesive reaches maximum strength 24-hours after Velcro® installation.
5. Center, stretch and attach the bumper as shown in Figures 2 and 3.
 - a. Bumper must completely cover the Velcro® to prevent dirt from attaching to adhesive.
 - b. Bumper must not hang below the vacuum-head, as this will impede the vacuum's performance.

Care Instructions

Remove dust and debris with a lint-roller, or machine wash and line dry.

VacuBumper.com ~ Service@VacuBumper.com ~ (480) 699-1172
10645 N. Tatum Blvd., Suite 200-377, Phoenix, AZ 85028



Figure 1



Figure 2



Figure 3