

# ProHOME™

## UCD-1002 Tank Quick Disconnect Installation (Optional Connectors)

The UCD-1002 is a quick disconnect connector setup to help make removing and replacing tanks 1, 2 and 3 with the ProHOME™ 3 tank systems **easier** – no plumber required (for tank replacement). Requires 1 setup for the inlet to tank 1 and one setup for the outlet on tank 3. Each UCD-1002 setup includes a PVC union coupler, 2-lead free brass fittings, 2-copper clamp rings and a piece of PEX tubing, fully assembled. Sold in pairs. Follow instructions for tank replacement in the ProHOME™ Installation Guide or see general information below.

### Installation:

1. For a new system installation, follow system installation instructions.
2. Install one UCD into the inlet of tank 1 using Teflon tape
3. Plumb the water source line into the female side of the UCD-1002
4. Remove the quick connect on the outlet side of tank #3. Insert the male side of the other UCD using Teflon tape  
SEE IMAGE BELOW.
5. Plumb the outlet side of the UCD-1002 to the ElectroCharged housing on the inlet side
6. Test for leaks upon completion of installation
7. For existing system, consult the instruction booklet for tank removal instructions.
8. Follow 2, 3, 4, 5, and 6 above

### Tank Replacement:

1. Turn off main water supply line.
2. Turn on a faucet to drain water and release any pressure
3. Unscrew both UCD-1002 union couplers
4. Easily slide out OR remove tank(s) for replacement
5. Replace necessary tank(s)



UCD-1002 Inlet side of tank #1. Female end of the UCD-1002 goes to the water supply line.

UCD-1002 Outlet side of tank #3. Connect to the ElectroCharged™ housing.