

VW SCIROCCO MK.I
FLOOR AND BULKHEAD SOUND DEADENING KIT
Part No.CK5583
FITTING INSTRUCTIONS



We would suggest that you start by fitting the main bulkhead felt. You may need to cut/slit the felt to allow it to sit comfortably on the bulkhead. The other two pieces lie alongside the main piece. We suggest you glue these pieces in place with an aerosol adhesive. You will find a beige piece of felt in the kit-this lies on top of the gearbox tunnel around the gearlever area. Again glue this in place. The two transmission pieces can also be glued in place. The four foot well felts do not need to be glued in place.

VW SCIROCCO MK.I
FLOOR AND BULKHEAD SOUND DEADENING KIT
Part No.CK5583
FITTING INSTRUCTIONS



We would suggest that you start by fitting the main bulkhead felt. You may need to cut/slit the felt to allow it to sit comfortably on the bulkhead. The other two pieces lie alongside the main piece. We suggest you glue these pieces in place with an aerosol adhesive. You will find a beige piece of felt in the kit-this lies on top of the gearbox tunnel around the gearlever area. Again glue this in place. The two transmission pieces can also be glued in place. The four foot well felts do not need to be glued in place.