

VW SCIROCCO MK.I
REAR PARCEL SHELF REFURBISHMENT KIT
CK5585



Lift out the shelf from the car and remove any staples or tacks that hold the carpet to the underside of the tray. It may be necessary to use sandpaper to clean off any old glue particles that are left on the board once the carpet is removed. At this time you can repair or repaint the bars of the tray.

Apply spray adhesive to both the back of the new carpet and the top of the board. Allow to dry slightly, then

position the carpet squarely over the board and press into place. Once completely dry, turn the edges of the carpet over the board and staple or tack in place.

VW SCIROCCO MK.I
REAR PARCEL SHELF REFURBISHMENT KIT
CK5585



Lift out the shelf from the car and remove any staples or tacks that hold the carpet to the underside of the tray. It may be necessary to use sandpaper to clean off any old glue particles that are left on the board once the carpet is removed. At this time you can repair or repaint the bars of the tray.

Apply spray adhesive to both the back of the new carpet and the top of the board. Allow to dry slightly, then

position the carpet squarely over the board and press into place. Once completely dry, turn the edges of the carpet over the board and staple or tack in place.