

**VW SCIROCCO MK.I
REAR PARCEL SHELF REFURBISHMENT KIT
CARPET AND BOARD**

CK5586



Lift out the shelf from the car and remove any staples or tacks that hold the carpet to the underside of the tray. It may be necessary to use sandpaper to clean off any old glue particles that are left on the board once the carpet is removed. Once the carpet is removed you will see how the two metal bars are held in place. Perhaps using a pair of pliers, turn back the metal flaps that go through the board. At this time you can

repair or repaint the bars of the tray. Replace the bars in the new board and lock the flaps into place.

Apply spray adhesive to both the back of the new carpet and the top of the board. Allow to dry slightly, and then position the carpet squarely over the board and press into place. Once completely dry, turn the edges of the carpet over the board and staple or tack in place.

**SCIROCCO MK.I
REAR PARCEL SHELF REFURBISHMENT KIT
CARPET AND BOARD**

CK5586



Lift out the shelf from the car and remove any staples or tacks that hold the carpet to the underside of the tray. It may be necessary to use sandpaper to clean off any old glue particles that are left on the board once the carpet is removed. Once the carpet is removed you will see how the two metal bars are held in place. Perhaps using a pair of pliers, turn back the metal flaps that go through the board. At this time you can

repair or repaint the bars of the tray. Replace the bars in the new board and lock the flaps into place.

Apply spray adhesive to both the back of the new carpet and the top of the board. Allow to dry slightly, then position the carpet squarely over the board and press into place. Once completely dry, turn the edges of the carpet over the board and staple or tack in place.