

CORRADO STD/DELUXE UNDERFELT FITTING INSTRUCTIONS



This is a fairly straightforward task; begin by laying the felt kit pieces into the foot-well areas front and rear. These will need trimming to fit exactly, in particular to clear the wiring loom and also to provide the best fit around the tunnel shape. When completed, use spray adhesive to fix the felts to the floor pan. If you are fitting a deluxe eight piece kit, stick the felts together using the adhesive also.