

# **FITTING INSTRUCTIONS**

## **TYPE 2 VAN 1968-72 SEAT COVERS SC7281/82/83**

Remove old covers taking care not to break the metal securing spikes, inspect the frames checking for damage such as breaks or cracks, also inspect the padding an repair as needed.

### **FITTING THE OPEN BACK SQUAB**

1. Slip cover over the frame and padding pull into place ensuring the cover is central
2. There is a flap at the bottom of the cover with a wire inside, pull this through to the back of the seat and over the spikes on the bar at the back of the frame ensuring the wire is over the spike or the vinyl will split
3. Tap the spikes over with a small hammer to secure the flap
4. fix the top flap to the frame in the same way
5. Pull the side skirts over the spikes on the side of the frame and tap them down also

### **FITTING THE CLOSED BACK SQUAB**

1. Slip the cover over the frame and padding making sure the cover is central
2. Pull the flaps (at the bottom of the cover) over the spikes at the bottom of the frame ensuring the wire is over the spikes or the vinyl will split and tap the spikes over (fix front flap first and pull back flap over the top of front flap)

### **FITTING THE BASE**

1. Pull cover over the frame and padding ensuring the cover is central
2. Make sure the skirt of the cover is pulled over the bottom of the frame and pull the wires tight so that the skirt is pulled tight to the bottom of the frame
3. Fix wires to frame when cover is tight
4. Pull the flap at the rear of the cover over the spikes ensuring the wire is over the spikes or the vinyl will split and tap the spikes over
5. Push the rest of the spikes through the vinyl ensuring the wire is over the spikes to stop the vinyl splitting and tap them all down

In the event of spikes breaking off, we can supply you with some C clips to fasten the cover to the frame. These are easily fitted using a small hammer, but are more visible when fixed.

