

VW GOLF MK.II

3 DOOR HATCHBACK SALOON

CARPET UNDERFELT KIT FITTING INSTRUCTIONS

Tools required – Scissors-sharp knife-spray adhesive

We would suggest that you read these instructions first to familiarise yourself with the procedure of fitting. Lay the felt set out on the floor.

We are assuming that you have removed all the seats, old carpet and under felt pieces and the centre console.



Stage One – The very hard green felts need to be glued directly to the floor as shown here making sure the wiring looms are tight against the sills. The sides of the rear felts should fit inside the seat runners. Trim around loom fixings.



Stage Two – These three pieces need to be glued to the top rear of the tunnel by the gear lever. You will see there is a recess in the metal and these pieces will fill that gap.



Stage Three – You will find two main tunnel felts. Place the large piece over the tunnel as shown and glue in place. Now glue the second felt on top of the first one.

Stage Four – Place and glue the last tunnel piece in place as shown here. Join all the edges for a smooth finish.



Stage Five – Two egg shaped pieces need to be fitted around the hand brake cables. Spray glue on one side then fold in half. Each piece will then sit either side of the cables to fill the gap.



Stage Six – The two longer parts can now be glued over the cables as shown here.



Stage Seven – The Bulkhead Felts-we have not shown them in the car-basically from the photo above you can see how they fit together. This kit will fit both LHD and RHD drive cars but you may have to trim separately around the steering columns. You will find three or four metal posts in the bulkhead where the carpet clips are situated. Using a sharp knife cut a slit in the felt where the white crosses are in the photo. Adjust the felt so all edges are together. Trim around wiring looms as necessary. Glue in place.

Stage Eight - The last floor pieces can now be laid in place, trimming where necessary so that various edges are flush with each other. Make sure pieces are inside the wiring looms and are flush with the tunnel carpet. The rear pieces should sit inside the seat runners. Glue in place.



Happy motoring

Copyright Newton Commercial 2011