

KARMANN GHIA FREQUENTLY ASKED QUESTIONS

Newton Commercial carpet sets are made to fit your vehicle and we ask a few important questions to make sure that parts supplied are correct for your make and model. We want to make sure you order exactly what your vehicle needs; giving the best possible end result with minimal fuss. If you are unsure of any of the requirements please read the below...

Does your vehicle have metal footrest tin in the passenger foot well?



Some cars had a metal plate fitted in the passenger foot well which affects the length of the foot well carpet we need to provide. As the picture indicates this plate angles the foot well which makes the passenger footrest more comfortable. As standard these were fitted to models after August 1959 but these are easily removed or added so best to check before ordering.

Year of vehicle

While our kits are offered as period specific there are actually some changes during these year breaks in some instances. This can affect the shape of the carpets. You should be able to check the year of your vehicle using the vehicle chassis number.

Check your tunnel

The kits we produce have tunnel dimensions as per this image. This measures the distance between the gear lever and the handbrake – if these do not match your vehicle please let us know before ordering

