

MORRIS MINOR SUFFOLK SEATS SUBFRAME

We are supplying the Sub frame separately from the seat as they can get damaged in transit.

- 1) Line the seat runners up equally so the holes are all parallel.
- 2) Insert the bolt through the seat runner so that the head is facing the underside of the seat.
- 3) Place the sub frame over the runners and screw Nyloc nuts in place.
- 4) Use 13mm open ended spanner and a 13mm socket to tighten all bolts
- 5) Happy Motoring.

