

## VW TYPE 4 VAN FITTING NEW CAB CARPET

Tools required:- No.1 & 2 Posidrive—sharp knife—13mm & 15mm socket or spanners.

Please read this instruction first as it will give you an idea of the procedures involved.

### **REMOVE FRONT SEATS.**

Use 15mm socket to remove four nuts holding sub frames to the floor. On the bench seat, use 13mm socket to remove an extra nut at the back of the frame.

### **REMOVE SIDE STEP PLASTICS.**

Using a marker pen, draw around the top edge of the plastic step insert where it meets the old floor mat. These side steps are held in place by various clips. One at either end near the rubber seal, three locating tags on the flat back edge and two in the base area. Make sure you retain all clips.

### **REMOVE CENTRE CONSOLE.**

Using No. 1 Posidrive remove four screws holding panel above console. Open glove box and remove self tapping screw on RH side. Use No.1 Posidrive to remove 3 screws holding main console.

We would suggest that you trim off the rubber mat inside of the marker pen line, this will allow the side step to sit in place, if not trimmed, the extra thickness of carpet will not allow the clips to secure properly.



### **FITTING NEW CARPET.**

Insert new carpet over handbrake and gear lever. Push the footwell sections up and around the pedals. The flaps on the sides in the console will just lie in place and the main footwell carpets will push them into position. Refit the centre console and the side step plastics making sure everything pushes into place. Finish off by refitting the seats.

Happy motoring.