

## **VW TYPE 2 1968-72 + 1973-79 2/3 BENCH SEAT FITTING**

### **INSTRUCTIONS SC7280 + SC7290**

1. Remove original covers being careful not to break any of the metal spike retainers and keeping the metal rods from the original covers.
2. Inspect the frames and the seat padding and repair as necessary.
3. Starting with the base cover inside out place the cover over the padding lining up the piping on the edge of the cover with the edge of the padding.
4. Gently ease the skirt over the sides of the frame and pull it over the bottom of the frame.
5. Turn the whole frame over so you are working from the bottom of the frame and pull the wire at each end to tighten the skirt and attach the wires to the small holes at the back of the frame using pliers
6. There are holes in the edge of the frame, using hog rings attach the skirt to the frame using these holes
7. The base is now fitted.
8. To fit the squab cover pull the cover over the padding ensuring that it is straight and all the skirt are over the back of the frame.
9. Insert the metal rod into the squab covers bottom skirt then pull the skirt over the metal spikes at the bottom of the frame ensuring the bar is on the other side of the spikes or the vinyl will tear
10. Do the same for the side skirts and the large flap at the top of the cover
11. When you are happy that the cover is fitted correctly gently tap the spikes over to secure the bars using a small hammer.