

VW CORRADO

BONNET FELT FITTING INSTRUCTIONS

We would recommend that you remove the bonnet from the car before trying to fit this kit. Clean the area and remove any grease or oil.

Apply the glue evenly around the edges and the centres of the bonnet felt and to the corresponding area on the bonnet.

Follow the instructions of the glue manufacturer.

Press the pad onto the bonnet and allow to dry properly for at least 24 hours before refitting your bonnet.

VW CORRADO

BONNET FELT FITTING INSTRUCTIONS

We would recommend that you remove the bonnet from the car before trying to fit this kit. Clean the area and remove any grease or oil.

Apply the glue evenly around the edges and the centres of the bonnet felt and to the corresponding area on the bonnet.

Follow the instructions of the glue manufacturer.

Press the pad onto the bonnet and allow to dry properly for at least 24 hours before refitting your bonnet.