

Installation Tips

Manual:

1. Do not lay out in windy conditions
2. Place a heavy stone in each corner of starting at end of the roll
3. Put a pipe or broom handle through core and slowly unroll
4. As you unroll, put plenty of soil on the edge of the entire roll or place 2x4's along both edges or use our **BioPegs** along with soil to hold in place and prevent wind from getting under the WeedGuard.
5. After roll is fully unrolled - Remove heavy stones at start



Mechanical Layer:

1. Do not lay out in windy conditions
2. Take all sway out of 3 point hitch
3. Be sure all tension is off of Mulch Organic roll
4. Trailing press wheels must be 90° vertical
5. Trailing press wheels must ride on outer 2" of the width of the roll

