

# FITTING GUIDE - PANIGALE US DRYPACK FIT KIT



Remove the pillion seat, unscrew and remove the rear cover.

Slide the webbing strap over the rear plastic with the loops facing upwards. *(top view)*



Locate the webbing between the inner and outer plastics, this maybe a tight fit. Once secured, then replace the rear cover.

*(underneath view)*



Slide an M5 washer inside each hypalon end of the 2 x bolt-on loops.

Add another M5 washer on top and screw in position using the M5 allen head bolts as illustrated here.



Replace the pillion seat and you have four hook-on points to mount any of the range of Kriega US-Drypacks.