

Hello!

Thank you for your order. Please ensure everything arrived as expected and do not hesitate to contact us if this is not the case.

If everything is correct please refer to the basic installation guide below as well as some maintenance tips to keep your new mailbox looking beautiful.

Thanks again!

Mailbox Post Instructions

Included

- 1 – Mailbox Post
- 1 - Mailbox

Needed:

- Gloves for protection and Post-hole Diggers or Shovel
- Phillips head screwdriver
- Level
- Quick Setting Concrete (60 lb. bag)
- Access to water (Approx. 5 gal.)

Installing the Post

1. In your desired location, dig a hole roughly 12” round by 16” deep. Place the post into the hole **making sure it is properly oriented so that either flat (non-slotted) face of the 6” x 6” post is facing the same direction the mailbox will face.** The tabs on top of the post should be orientated front to back for proper mailbox installation. If you have purchased a 3” round post make sure to orient the shortest edge of the post mounting bracket in the same direction the mailbox will face.
2. With post in the hole, pour dry mix Quickset concrete around the post to fill the hole ½ way full while keeping the post as level as possible.
3. Fill the hole with water. We recommend using a stick or rod to poke the concrete mix to help it settle and allow the water to penetrate.
4. Using a level, level the post on two adjacent vertical sides. The concrete should hold it stable.
5. Add more quickset concrete to fill the hole to a few inches below the surface of the ground if you plan to fill dirt or mulch back in around for a clean look.
6. Check level again, secure as needed and allow to cure per concrete directions before installing the mailbox.

Attaching Modern Mailbox to Modern Post

1. A mailbox mounting bracket is secured to all post-mounted mailboxes with 4 Phillips head M5 bolts. This can be left in place. Place the mailbox on top of the installed post, making sure to align the threaded holes on the mailbox mounting bracket with the mounting slots of the post.
2. 4 additional M5 bolts are included in the mailbox mounting bracket. These bolts are already screwed into the holes that align with the post. Remove these bolts (nothing will come loose) and save these bolts to attach the mailbox to your installed mailbox post.

***If you are installing your mailbox onto an existing or different style post other than a Deus Modern Post; the bottom mounting bracket is aluminum and can be easily drilled into and secured with self-tapping sheet metal screws.

Mailbox Care

The mailbox wood is finished with Cabot Australian Timber Oil - Natural Finish. It is recommended to apply additional coats as needed to areas showing signs of wear, approximately every 8-12 months. The wood will grey naturally if this is not done, which can be a beautiful aesthetic. This is easily done with a clean rag and a bottle of Cabot Australian Timber Oil – Natural finish available at hardware stores or online from Amazon for about \$20. Cover metal surfaces with protective tape as needed to keep free of oil.

Powdercoated shells may be cleaned with a soft, non-abrasive towel and soap and water. Do not use strong chemical cleaners.

Stainless Steel shells may be cleaned with a soft non-abrasive towel and stainless steel cleaner.

Should you have any questions about your new mailbox please contact us via email at Hello@DeusModern.com.

Thank you so much for your order!

-The Deus Modern Team