

STEP 1 To attach the bracket to the rails of your seatpost, remove one or two of the black-anodized screws from the alloy frame. (Also enclosed are the original silver screws from Minoura, which you may use as back-ups.) Orient the backplate as shown with the wider side down. Slip the back plate into position on top of the rails. Be sure to keep the lock washers in place near the screw head. Also refer to the enclosed instructions from Minoura.



STEP 2 Keep the gray webbing & female buckle centered between the two screws. When tightening down the bolts, don't over do it—it only needs to hold a bag, not the weight of a person! Using a long T-handle Allen wrench makes the job easier. (You may have better luck by removing the entire seatpost.)



If you are using the Wide Rail Bracket Adapter for Brooks-type saddles, refer to that specific instruction sheet.

STEP 3 Orient the L bracket as shown, i.e. like an up-side-down "L." The exact angle of the bracket is determined by the angle of the rails at the rear of your saddle and may differ from model to model.



STEP 4 Take the *thick* pair of Velcro loop tabs on your bag and slip them through the pair of nylon rectangular Uniloops (look for *red* webbing on newer some models).



STEP 5—STANDARD L BRACKET Take the thin Velcro hook and wrap it around the other side of the bracket.

STEP 6—HIGHBOY OR SUPERSIZE L BRACKETS Wrap the Velcro back onto itself, instead of on the back side of the bracket.

STEP 7 The roll top bags have an elastic "hold open strap" which serves two purposes:

1. It is for keeping the bag upright while filling or accessing. Pull it over nose of your saddle. When you roll up the bag, tuck this strap into the roll.
2. The Rolltop bags can also be used off the bike & not connected to a bracket, as a shoulder bag. Roll down the bag and slip this elastic over the top of the bag & clip it to a D-ring to keep the top closed while using the bag.



BAG FEATURES (See photo on page 1). The top row of webbing with reflective tape is for attaching either the Reflective Yield Symbol (#3624-0E0) or the Piggy-back Pocket 2.5 (#2125-K00). Some use it for attaching blinky lights, but the angle of the light can vary when attached to any soft bag, so we suggest attaching them to your seat stays instead.



The D-rings for attaching apparel or gear like a spare tire. Use a pair of optional D-rings Straps (#2445-KMD).

The thin black webbing near the bottom is for attaching the bottom Velcro straps of a Yield Symbol or the Piggy-back pocket.

- 2314-KSL **Standard "L" Saddle Bracket** (w/ Minoura SBH-300 frame)



6 80474 82361 1

- 2315-KHB **Highboy "L" Saddle Bracket**
(standard bracket with 2352 Highboy Extender Plate attached)



6 80474 82368 0

- 2317-KSS **Supersize "L" Saddle Bracket**
(standard bracket with 2353 Supersize Extender Plate attached)



6 80474 82364 2



If the printed photos are unclear, view this as a PDF document online instead at www.eogear.com/how-to/



ONE Attach the bracket to your saddle rails. See steps 1 thru 3 on page one.



TWO Attach the empty bag to the bracket. See steps 4 & 5 on page two.

THREE Clip the compression straps to the bracket in this order: A, B and C.



FOUR After clipping them in, be sure to slip the loose ends of webbing back onto itself using the "slotted uniloop," otherwise the strap might end up in the spokes of your wheel!

NOTE Shown is a RandoBag Rolltop model (6.6, 8.2 or 9.3). The Zippered 6.8 mounts similarly.