

## ROLLTOP SEATBAG<sup>™</sup> INSTRUCTIONS

If these photos are unclear, view this as a PDF document online instead at www.eogear.com/how-to/



# 3120-GIA **RollTop SeatBag™ 12.0** (Black + Gray)



**12.0 Bag Shown with Optional Accessories** eoGEAR Piggy-back Pocket on top (# 2125-K00) Attach with the zipper facing to the rear.

> Equinox Horizontal Pack Pocket (# 4924-000) Attaches to the side or top of the bag.

On the top are two pair of webbing strips with slots for attaching other pouches, especially the eoGEAR Piggy-back Pocket.

D-rings for attaching gear.

This row of webbing is the DTS attachment point for piggy-backing extra pouches onto the sides of the bag.

## ASSEMBLY STEPS

**STEP 1** Attach the Rail-Rebar Adapter (RRA, Velcro straps with the aluminum bar sewn in) to the bottom of the rails, just above the *bend* of your saddle. Slip the Velcro straps up through the center of the rails and out to the side (similar to conventional wedge bags).



**STEP 2** After filling the bag, cinch down the main compression strap loosely. Slip the strap through the skinny webbing loop on top of the bag.

**STEP 3** Attach the Velcro strap to the seatpost. Hike it up as far as possible without deforming the shape of the bag. BE SURE YOU HAVE PLENTY OF CLEARANCE above the tire, especially when using a bike with rear suspension.

**STEP 4** Cinch down the side straps so they are very tight. Clip in the loose ends of the webbing.

**STEP 5** Cinch down the main strap more if needed.

Inside Compression Strap. Inside the bag is a compression strap for doing intermediate load squishing.

