

# Vandgard®

## Fitting between walls

Alleyways and corridors are common access places for intruders

Vandgard® can be securely fixed to span 2 metres or more between walls using our Internal Sockets (VIS01)

- Position the Internal sockets on the wall, mark and and drill holes for M8 masonry screws
- Cut the shaft to size and thread the vanes along its length.
- Place the sockets on each end and lift into position
- Tap M8 fixings into pre-drilled holes and tighten.



**VIS001 Internal Socket**