

# Vandgard®

## Fitting to walls

Intruders use the stable platform at the top of a wall to aid climbing.

Vandgard® safely and securely prevents access over walls and ledges

- Position the first support bracket on the wall, allowing 300mm horizontally from the end of the run and allowing at least 50mm clearance for the vanes to rotate.
- Fix with 2 x M8 masonry screws, drill and tighten.
- Thread the vanes in pairs along a 2metre length of shaft, insert a joining spigot in the end and lift into position.
- Fit the second support bracket over the end of the shaft no more than 2metres apart and hammer the next 2m shaft onto the joining spigot, thread the vanes in pairs and repeat.
- Allow 300mm overhang at the end of the run to prevent intruders using the end support bracket as a climbing aid
- Crimp the end of the shaft to a neat oval shape using a hammer and dolly

