

EVERLAST CLIMBING INDUSTRIES, INC.

INSTALLATION INSTRUCTIONS: OUTLET FRAME



Materials Included:

Outlet Frame
1-5/8" Screws

Tools Needed:

Drill w/ #2 Phillips bit

INSTALLATION INSTRUCTIONS:

(Please read all instructions thoroughly before starting to install)

1. Place the outlet frame against the desired location on the wall panel cutout.
2. Using a drill and #2 Phillips bit, attach the outlet frame to the panel with the included five 1-5/8" screws.



THE PROPER CARE AND ONGOING MAINTENANCE OF YOUR CLIMBING WALL IS ESSENTIAL AND IS YOUR RESPONSIBILITY. PLEASE REFER TO THE SAFETY, CARE AND MAINTENANCE INSTRUCTIONS.