



New Sprinter 907 - 2019 + Front emblem installation

***All black grill - No chrome (below) / Chrome grill (reverse)**

Required tools: Small screwdriver / prying device.

Removal

1. Locate the bottom of the chrome emblem.
2. Carefully insert your prying device / screwdriver under the emblem at the 6 o'clock location.
3. Gently pry the emblem away from the grill until the tab is free.
4. Pivot the chrome emblem upwards slowly.
5. The top tab will release last.



Installation

1. Center the emblem to the grill, it only fits one way.
2. Insert the upper locking tab first at the 12 o'clock position.
3. Work from the top, press the emblem into place until all locking tabs have seated.





New Sprinter 907 - 2019 + Front emblem installation

Grill w/ chrome strips

No tools required. Simply grab the emblem and twist counter clockwise and remove. Replace the emblem and twist clockwise to lock emblem in place.

Fine print:

Our black emblems are coated with a ceramic coating used on firearms. The coating is hard and very durable but is not 100% impervious to severe impacts. You may still receive a chip on the coating. Just want to be clear, this product is hard and durable, and could and most likely will chip.

Because of this we can't offer a warranty against chips or damage from foreign objects. Sorry.

