

TERRAWAGEN Vanagon / Transporter Bug Barrier

Thanks for buying our products!

Installation instructions for your New Bug Barrier.

1. Roll the window completely down
2. Place the Bug Barrier in the opening as shown
3. Rotate Bug Barrier into weather strip gap
4. Push Bug Barrier up until it stops
5. Roll window up until glass enters the slot.
6. 1st roll up may need help. If the glass does not enter the slot, fold this instruction sheet lengthwise and put it in the slot to assist the glass as it enters.
7. The longer the glass stays inside the slot the easier it will be the next time.

