



TERRAWAGEN

VANAGON - TRANSPORTER FENDER FLARE KIT TWFK-003

This instruction sheet is specifically for late model Vanagon and Transporters that have the large fiberglass bumpers.

FRONT MODIFICATIONS

1. The front door flares only need very minor trimming at the very bottom only if you have the factory plastic air dam in place.
2. The rear sections of the front flare (2 small parts) have a score mark on the inside of the parts. Look carefully, the lines are very faint. These lines are there as a guide for you to cut.
3. Using tin snips, cut the part along the line. This is your initial cut. fine tuning is required to make the part fit YOUR van. Because every van has a different fit of the bumpers.
4. Use a file, or we prefer to use a Dremel with a drum sander bit. Gently file the part as you fit. It will take you a few tries to get the part to fit around the cladding. * see picture *



REAR MODIFICATIONS

1. Similar to the front part, the rear flares have the same witness marks on the inside to show you where to trim.
2. Same as above, use tin snips to cut along the line but not past it. Use a file or dremel tool with a drum sander attachment to fine tune the fit until the flare can be screwed in place.

