



Terrawagen

Seat base storage pocket

Installation instructions

1. Before installing, test fit pocket to see where you would like to place it.
 2. Clean painted surface of Sprinter seat base with a cloth and alcohol.
 3. Remove tape backing
- * **IMPORTANT*** Once the tape makes contact you can not remove it to adjust placement.
4. Carefully place pocket in desired area.
 5. Apply firm pressure (25 lbs) to exterior of pocket in the taped areas.
 6. Allow 24 hours for tape to cure before you load it up.

