



Check out our install video here—>



Terrawagen Tidy Trim Kit Front

TWNS-48

Installation instructions and contents:

Thanks for buying Terrawagen products! This kit is specifically designed for 2019 and newer Sprinter High Roof models. Pieces are designed to interlock and be covered with fabric, some sanding and fitting may be required.

Kit contents: 7 piece front trim segments, hardware pack, Jelly beans

Threaded standoffs are for the upper slider door segment. Thread standoffs over existing sprinter upper track studs. Foam blocks have an adhesive strip and are designed to keep the slider door segment pushed against the slider door rubber seal. See figure 1 for standoff configuration and foam block location. Push segments into the factory seal at perforation firmly to lock into correct positions. “C” Pillar segments and window surround attach with supplied self tapping screws.



1. Window Surround
2. Headliner Void Driver Side
3. Headliner Void Passenger Side
4. Slider Door Upper
5. C Pillar Upper
6. C Pillar Lower
7. C Pillar Middle

